





CONNECTOR USED ON MOST STUDIO RADIOS FOR HEADSETS / HAND MICS

M1		Motorola	CP100, CP150, CT150, CT250, CT450, CT450LS, GP2000, GP300, GP308, GP280, GP68, GP88, GTI, GTX, LTS2000, P040, P080, P110, P1225, P1225LS, P200, PR400, PRO3150, SP10, SP21, SP50, XTN446, XTN500, XTN600, XV1100, XV2100, XU1100, XU2100, XU2600, VL130, VL50, GP320, GP328, GP329, GP338, GP339, GP340, GP350, GP360, GP380, GP640, GP650, GP680, GP1280, GP2000
		Blackbox	Blackbox-V, Blackbox-U

CONNECTORS USED FOR NEXTEL RADIO HEADSETS / SPEAKER-MICS

E		Nextel	i1000plus, i2000plus, i700plus, i2000, i1000, i550plus, i500plus, r750plus, r750plusFM
C		Nextel	i60c, i95cl, i90c, i30sx, i35s, i88s, i80s, i55sr, i58, i85s, i50sx
F		Nextel	Nextel Falcon Series; i205, i265, i275, i305, i315, i325, i355, i530, i560, i605, i710, i730, i733, i736, i760, i830, i836, i850, i860, i870, i930